Preventative Maintenance Kit (SP2G7712) Includes:



Brush – Input
(P/N#: SP8H5613)



Filter Light Lock, Erase(3)
(P/N#: SP2G4471)



Foam
(P/N#: SP2G3232)
Filter
(P/N#: SP2G3224)

Seal Light Plushes (6)
(P/N#: SP2G3313)

Seal – Light Flex Tray
(P/N#: SP2G5204)



Plush Strip
(P/N#: SP2G6588)
Seal, Light Plush (2)
(SP2G6589)

Part #	Description	Qty Included
SP2G7712	**Preventative Maintenance Kit Includes:**	
SP8H5613	Brush - Input	1
SP2G3232	Filter, Foam	1
SP2G3224	Filter, Air Intake	1
SP2G4471	Filter – Light Lock, Erase	3
SP2G3313 (replacement for SP2G6062)	Seal - Light Plush	6
SP2G5204	Seal - Light Flex Tray	1
SP2G6589	Seal - Light Plush	2
SP2G6588	Seal - Light Plush	1

Air Filtration Replacement Parts



Part #	Description	Qty Required
SP2G4471	Filter, Light Lock, Erase	3
SP2G3232	Filter, Foam	1
SP2G3224	Filter, Air Intake	1

Brush and Plush (felt) Replacement Parts

Cassette Tray



Roof Assembly (upside down)



Flex Feed Tray



Part #	Description	Qty Required
SP8H5613	Brush - Input	1
SP2G3313 * (replacement for SP2G6062)	Seal - Light Plush	6
SP2G5204 *	Seal - Light Flex Tray	1
SP2G6589 *	Seal - Light Plush	2
SP2G6588 *	Seal - Light Plush	1

Parts denoted by an (*) are only available as part of the Preventative Maintenance Kit P/N#: SP2G7712.

Erase Bulbs - Replacement Parts

Removing Erase Assembly



Locating Erase Lamp Tester Buttons



(P/N#: SP8G6041)

Part #	Description	Qty Required
SP8G6041	Bulb Erase (unit uses 15 bulbs, replace as needed)	As needed